

Scope of Work Blacktop

2" Mill/Fill:2,500 SF severe cracking noted

- Saw-cut and excavate area to a depth of 2."
- Clean area of all debris
- Apply a tack coat adhesive
- Patch areas with 2" of surface asphalt and compact.
- Apply hot rubberized tar to seal edges.

Sealcoating: approximately 36,000 SF lot

- Clean lot of all debris
- Apply oil spot primer to major oil stains in lot.
- Seal lot with two coats gas/oil resistant sand sealer with latex additives for extended wear.
- Apply a third coat to the main entrance.

Crack filling:

- Route major ¼" cracks or wider in lot to ½" width and depth.
- Clean with air compressor.
- Apply hot rubberized tar to major routed cracks.
- Seal area around concrete pad

Striping: (All Areas)

- Re-stripe to requested markers.

